80g 双胶纸　开折页　单黑正反面印刷　成品尺寸：80*234mm

SEAGO

声波电动牙刷
Electric Toothbrush SG-2750 (S5)
/
Instruction Manual
使用说明书

Instruction Manual (EN)

Precautions

1. Please read this manual carefully before use and keep it for future reference.
2. This product cannot be used by persons with physical, sensory, or mental disabilities, or those lacking experience and knowledge unless supervised, unless they are supervised or instructed by a responsible person regarding the safe use of the appliance.
3. Children should be supervised to ensure they do not play with the appliance.
4. This is a Class III appliance. It must only be powered by a Safety Extra-Low Voltage (SELV) supply as marked on the appliance. The power supply shall have a measured maximum output power of less than 15 W at its output terminals. When charging the product via a connection to a charging cable, the power supply shall have a rated voltage of 5V and a rated output current of 1 A, and shall also comply with the Safety Extra-Low Voltage (SELV) requirements of standard GB/T 4706.1-2024.
5. Ensure the charging port is completely dry before charging. Please use the original charging cable provided in the package.
6. This product contains a rechargeable battery. Do not attempt to replace it yourself.
7. Do not disassemble, repair, odor, overheating, or malfunction occurs, stop using immediately, immediately turn off the switch, and disconnect the power supply.
8. Do not attempt to disassemble, repair, or modify the product yourself. If you encounter any issues, please contact us. All repairs must be handled by our professional technicians; the product must be returned to our facility.
9. Turn off the appliance when leaving it unattended.
10. Do not use this product near flammable or explosive materials or in similar hazardous environments.
11. If you have undergone oral or gum surgery in the past 2 months, please consult your dentist before using this product.
12. This product is intended for cleaning teeth, gums, and the tongue only. Do not use it for any other purposes.
13. Do not use brush heads with deformed bristles. Replace the brush head immediately if signs of wear appear. It is recommended to replace the brush head every three months.
14. Use only genuine brush heads produced by our company.
15. If you use toothpaste containing baking soda (sodium bicarbonate), peroxide, or other carbonate ingredients (common in whitening toothpaste), thoroughly rinse the brush head after each use to prevent plastic cracking.

Product Specifications

Model: SG-2750 (S5)
Rated Input Voltage: 5V ⎓
Rated Input Power: 15 W
Charging Time: ≤ 4 hours
Operating Environment: 5-40℃ (41-104℉)
Product Dimensions: 27 × 26 × 247 mm (including brush head)
Waterproof Rating: IPX7
Materials: ABS / TPE / Nylon
Country of Origin: China

Parts Name

A-1 Brush Head
A-2 Power / Mode Button
A-3 Handle
A-4 Charging Indicator Light
A-5 Charging Port
A-6 Travel Case
A-7 Modes: Whitening, Clean, Sensitive, Polish, Massage

充电说明

1. 使用前请将其完全固定在手柄上，将清楚字幕的箭头上。
2. 将刷毛轻轻压浮在牙齿的空间，与牙面呈 45°角。(C-1)
3. 按动开关，使振幅均匀稳定，重复每一颗牙齿。
4. 刷过程中为了之，左下、右上，右下的顺序，每个区域的外侧、内侧、咬合面各刷 10 秒时间。(C-2)
5. 当一个区域刷满 30 秒时，产品会短暂停顿提醒您移动下一个区域继续清洁，2 分钟自动关闭。
6. 产品产品后，主刷毛会短暂保持振动模式，切换成弹力杯模式一键清模式一键柔模式一键光模式一键美模式一关闭一来回模式。
7. 日常的刷牙建议使用柔模式，清洁模式。
8. 当前刷牙模式下为一次开启产品时的默认刷牙模式。
9. 每次刷牙完成后请清理清水将牙刷清洗干净，每个月每 40℃ 以内的温水将其浸泡在清洗一次，注意清洗前请清洁其他表面。

功能特点

1. 每分钟高达 42000 次振动清洁口腔。
2. 产品具有四款，清洁、轻柔、抛光、按摩五大模式，满足不同牙齿需要的个性化需求。
3. 机身符合人体工程学设计，机身握感舒适手感，防滑防潮，握持舒适。
4. 内置大容量锂电池，续航模式下持续天深续航 2 分钟计算，第四周可使用长达 45 天。
5. IPX7 防水，全身不进水，使用更安心。
6. 采用新型 30 根微丝刷毛，分钟能够近到清楚式近切清。

故障诊断

情况	可能原因	解决措施
振动强度减弱	1.牙刷长期使用，刷毛磨损	更换牙刷头
牙刷工作时间短	1.牙刷未充满电，可能电池老化 2.电量不足	1.请充满电后使用 2.更换电池
牙刷不工作	1.电量不足 2.电池损坏	1.请进行充电 2.请联系售后维修

电池更换处理

本产品使用的是锂电池，产品寿命终止时，请勿自行拆卸，请联系客服中心，我们会为您提供专业的电池拆卸服务。若有疑问请直接与我们的售后部门。
拆除电池后需要妥善以下工具：螺子、剪刀。

刷头更换安装方法

B-1 安装：保持刷毛朝向牙齿并按压刷毛，将刷头对准机身上的连接槽头，正向装下即可。
B-2 拆卸：将刷头朝反方向用力即可拆出。

使用说明书 (CN)

注意事项

1. 使用前请仔细阅读说明书并妥善保管，便于日后参考。
2. 本产品不适合有肢体、感官或精神缺陷的人士，或缺乏相关知识和经验的人士（包括儿童），除非有负责他们安全的人员对他们进行产品安全使用有关的监督或指导。
3. 应照看好儿童，确保他们不玩耍本产品。
4. 本产品为 III 类器具，仅能使用标记设备具上的安全特低电压供电。铭牌电源应满足输出端口最大功率小于 15W，标配电源适配器产品其额定电压为 5V ⎓，额定输出电流为 1A 且同时满足GB/T 4706.1-2024 标准要求的安全特低电压（SELV）。
5. 充电时必须保持电池口干燥，请使用随附的原装充电线。
6. 本产品包含不可更换的电池。
7. 产品出现异常现象，异味气体，异常高温或出现碰撞，请立即停止使用，关闭开关，断开电源。
8. 不可自行拆开产品进行维修或改装，改造等，产品有任何问题请联系我们，如需维修必须将回品寄回专业人员维修处理。
9. 人员离开时，请关闭产品电源。
10. 本产品不适合易燃易爆物品附近或类似环境中使用。
11. 若您在近 2 个月接受过口腔或牙齿手术，使用本产品前请咨询牙医。
12. 本产品仅用于清洁牙齿、牙龈及舌面，请勿用于其他用途。
13. 请勿使用刷毛变形的刷头，如出现磨损请立即更换，建议每三个月更换一次刷头。
14. 产品出现故障请联系公司生产的专用牙刷头。
15. 若您使用的牙膏含有小苏打（碳酸氢钠）、过氧化物或其他碳酸盐成分（常见于美白牙膏），每次使用后务必彻底清洗刷头，以防塑料开裂。

产品参数

产品型号：SG-2750 (S5)
额定输入电压：5V ⎓
额定输入功率：1.5W
充电时间：≤4小时
防水等级：IPX7
工作环境：5-40℃
产品材质：ABS / TPE / 尼龙
详细尺寸：27×26×247mm（含刷头）
产地：中国

产品结构图

产品各有物资名称及含量		
有害物质	部件名称	
	刷头	牙刷手柄
铅(Pb)	○	○
汞(Hg)	○	○
镉(Cd)	○	○
六价铬 (Cr VI)	○	○
多溴联苯 (PBB)	○	○
多溴二苯醚 (PBDE)	○	○
邻苯二甲酸二丁酯 (DBP)	○	○
邻苯二甲酸二辛酯 (DOP)	○	○
邻苯二甲酸丁苄酯 (BBP)	○	○
邻苯二甲酸二异辛酯 (DEHP)	○	○
邻苯二甲酸二异壬酯 (DINP)	○	○

注：○：表示该有害物质在该部件的均质材料中的含量均在现行有关产品有害物质限制标准的限量要求范围内。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出现行有关产品有害物质限制标准的限量要求。
（以上表格内容为依据：单位提供有关部门出具的有关产品有害物质限制使用清单的有关资料。）

备注：
1. 有害物质含量超出现行有关产品有害物质限制标准的限量要求，但是现行有关产品有害物质限制标准尚未规定限量的，或现行有关产品有害物质限制标准尚未规定限量的，或现行有关产品有害物质限制标准尚未规定限量的，或现行有关产品有害物质限制标准尚未规定限量的。
2. 部件名称栏填写的不同，产品可能不包括以上所有部件，请以产品实际情况为准。

刷头安装及拆卸

C-1 安装：将刷头对准机身上的连接槽头，正向装下即可。
C-2 拆卸：将刷头朝反方向用力即可拆出。

Brush Head Installation and Removal

B-1 Installation: Align the brush head with the metal shaft on the handle, ensuring the bristles face the same direction as the button. Press the brush head down firmly until it is fully secured.
B-2 Removal: Pull the brush head upwards with force to detach it from the handle.

Operating Instructions

1. Install the brush head firmly onto the handle. Apply a suitable amount of toothpaste onto the bristles.
2. Place the bristles gently against the junction of your teeth and gums, holding the brush at a 45°angle to the tooth surface. (C-1)
3. Press the power button to start. Slowly move the brush head horizontally across each tooth.
4. Divide your mouth into four sections: Lower left, upper right, lower left, lower right. Spend 10 seconds brushing the outer, inner, and chewing surfaces of each section. (C-2)
5. The toothbrush will automatically pause for 30 seconds to remind you to move to the next quadrant. The appliance will automatically turn off after 2 minutes of continuous use.
6. Within 3 seconds of turning on the device, pressing the button will switch the mode. The switching sequence is: Whitening → Clean → Sensitive → Polish → Massage → Off → Clean.
7. If no button is pressed within 3 seconds, pressing the button again will turn off the device.
8. The mode used in the current session will be memorized and set as the default mode for the next time you turn on the device.
9. Rinse the brush thoroughly with clean water after use. Once a month, soak the handle (with the charging cover tightly closed) in water below 40℃ (104℉) for a deep clean.

Charging Instructions

1. When the red indicator light flashes or the device fails to turn on, the battery is low and needs to be charged.
2. Connect the toothbrush to a USB charger or a device with a USB port using the original charging cable provided.
3. The indicator light will give red duty during charging. Once fully charged, the light will turn green and then turn off automatically to prevent overcharging.
4. If the indicator light does not illuminate during the first 5 minutes of charging (especially during the first use or after long periods of inactivity), this is a normal self-protection mechanism due to extremely low battery levels. The light will turn on automatically shortly after.

Features

1. Up to 42,000 micro-vibrations per minute for a deep and thorough clean
2. Five cleaning modes (Whitening, Clean, Sensitive, Polish, and Massage) to meet personalized gum sensitivity needs
3. Ergonomic design that fits perfectly in your hand, ensuring anti-moisture-resistant for a comfortable grip
4. Built-in high-capacity eco-friendly lithium battery. A single full charge lasts up to 45 days (based on 2 minutes of use, twice a day, for a standard battery)
5. IPX7 waterproof rating allows for safe use in the shower and easy cleaning under running water
6. Smart timer with a 30-second quadrant alert and a 2-minute auto-shutoff, plus a convenient memory function.

Trouble Shooting

Issue	Possible cause	Solution
Reduced vibration intensity	Excessive pressure applied to the teeth	Gently press the bristles against your teeth without pressing hard
Shortened operating time	1. Improper placement leading to poor contact 2. Insufficient battery level	1. Reposition the toothbrush correctly on your teeth 2. Recharge
Device does not turn on	1. Battery is completely drained 2. Other internal issues	1. Charge the device 2. Contact SEAGO customer support

Battery Disposal

This product uses a lithium battery. When the product reaches the end of its life, please contact us for the battery disposal service. We properly according to local waste management regulations. Please consult your local waste disposal authority for specific recycling instructions.

Tools required for battery removal: Saw, Wire Cutters

Warning: Only remove the battery when discarding the product. Before disassembly, ensure the device is disconnected from the power supply and turned off. Completely drain the battery before removal. When using tools, strictly follow basic safety rules and take appropriate protective measures to avoid injury.

1. Remove the brush head. Use a saw to cut through the handle at the marked position (1.5mm from the top). (D-1 / D-2 Battery)
2. Image shown: Sawing effect (cross-section). (D-2)
3. Place the metal shaft of the toothbrush against a flat surface (like a desk). Hold the handle and press down firmly to push the internal bracket out. (D-3 / D-4)
4. Once the bracket is removed, cut the battery wires and take out the battery. (D-5)

Product Specifications

Model: SG-2750 (S5)
Rated Input Voltage: 5V ⎓
Rated Input Power: 1.5 W
Charging Time: ≤ 4 hours
Operating Environment: 5-40℃ (41-104℉)
Product Dimensions: 27 × 26 × 247 mm (including brush head)
Waterproof Rating: IPX7
Materials: ABS / TPE / Nylon
Country of Origin: China

Parts Name

A-1 Brush Head
A-2 Power / Mode Button
A-3 Handle
A-4 Charging Indicator Light
A-5 Charging Port
A-6 Travel Case
A-7 Modes: Whitening, Clean, Sensitive, Polish, Massage

充电说明

1. 使用前请将其完全固定在手柄上，将清楚字幕的箭头上。
2. 将刷毛轻轻压浮在牙齿的空间，与牙面呈 45°角。(C-1)
3. 按动开关，使振幅均匀稳定，重复每一颗牙齿。
4. 刷过程中为了之，左下、右上，右下的顺序，每个区域的外侧、内侧、咬合面各刷 10 秒时间。(C-2)
5. 当一个区域刷满 30 秒时，产品会短暂停顿提醒您移动下一个区域继续清洁，2 分钟自动关闭。
6. 产品产品后，主刷毛会短暂保持振动模式，切换成弹力杯模式一键清模式一键柔模式一关闭一来回模式。
7. 日常的刷牙建议使用柔模式，清洁模式。
8. 当前刷牙模式下为一次开启产品时的默认刷牙模式。
9. 每次刷牙完成后请清理清水将牙刷清洗干净，每个月每 40℃ 以内的温水将其浸泡在清洗一次，注意清洗前请清洁其他表面。

功能特点

1. 每分钟高达 42000 次振动清洁口腔。
2. 产品具有四款，清洁、轻柔、抛光、按摩五大模式，满足不同牙齿需要的个性化需求。
3. 机身符合人体工程学设计，机身握感舒适手感，防滑防潮，握持舒适。
4. 内置大容量锂电池，续航模式下持续天深续航 2 分钟计算，第四周可使用长达 45 天。
5. IPX7 防水，全身不进水，使用更安心。
6. 采用新型 30 根微丝刷毛，分钟能够近到清楚式近切清。

故障诊断

情况	可能原因	解决措施
振动强度减弱	1.牙刷长期使用，刷毛磨损	更换牙刷头
牙刷工作时间短	1.牙刷未充满电，可能电池老化 2.电量不足	1.请充满电后使用 2.更换电池
牙刷不工作	1.电量不足 2.电池损坏	1.请进行充电 2.请联系售后维修

电池更换处理

本产品使用的是锂电池，产品寿命终止时，请勿自行拆卸，请联系客服中心，我们会为您提供专业的电池拆卸服务。若有疑问请直接与我们的售后部门。
拆除电池后需要妥善以下工具：螺子、剪刀。

刷头更换安装方法

B-1 安装：保持刷毛朝向牙齿并按压刷毛，将刷头对准机身上的连接槽头，正向装下即可。
B-2 拆卸：将刷头朝反方向用力即可拆出。

使用说明 (TC)

注意事項

1. 使用前請仔細閱讀說明書並妥善保管，便於日後參考。
2. 本產品不適合肢體、感官或精神缺陷的人士，或缺乏相關知識和經驗的人士（包括兒童），除非有負責他們安全的人士對他們進行有關產品安全使用的監督或指導。
3. 應照看好兒童，確保他們不玩耍本產品。
4. 本產品為III類器具，僅能使用標記設備具上的安全特低電壓供電。銘牌電源應滿足輸出端口最大功率小於 15W，標配電源適配器產品其額定電壓為5V ⎓，額定輸出電流為 1A 且同時滿足GB/T 4706.1-2024 標準要求的安全特低電壓（SELV）。
5. 充電時必須保持電口干燥，請使用隨附的原裝充電線。
6. 本產品包含不可更換的電池。
7. 產品出現異常現象，異味氣體，異常高溫或碰撞，請立即停止使用，關閉開關，斷開電源。
8. 不可自行拆開產品進行維修或改裝，改造等，產品有任何問題請聯繫我們，如需維修必須將回品寄回專業人員維修處理。
9. 人員離開時，請關閉產品電源。
10. 本產品不適合易燃易爆物品附近或類似環境中使用。
11. 若您在近 2 個月接受過口腔或牙齒手術，使用本產品前請諮詢牙醫。
12. 本產品僅用於清潔牙齒、牙龈及舌面，請勿用於其他用途。
13. 請勿使用刷毛變形的刷頭，如出現磨損請立即更換，建議每三個月更換一次刷頭。
14. 產品出現故障請聯繫公司生產的專用牙刷頭。
15. 若您使用的牙膏含有小蘇打（碳酸氫鈉）、過氧化物或其他碳酸盐成分（常見於美白牙膏），每次使用後務必徹底清洗刷頭，以防塑料開裂。

產品參數

產品型号：SG-2750 (S5)
工作环境：5-40℃
額定輸入電壓：5V ⎓
產品材質：ABS / TPE / 尼龍
額定輸入功率：1.5W
詳細尺寸：27×26×247mm（含刷頭）
充電時間：≤4小時
產地：中國
防水等級：IPX7

產品結構圖

產品各有物質名稱及含量		
有害物質	部件名稱	
	刷頭	牙刷手柄
鉛(Pb)	○	○
汞(Hg)	○	○
鎘(Cd)	○	○
六價鉻 (Cr VI)	○	○
多溴聯苯 (PBB)	○	○
多溴二苯醚 (PBDE)	○	○
鄰苯二甲酸二丁酯 (DBP)	○	○
鄰苯二甲酸二辛酯 (DOP)	○	○
鄰苯二甲酸丁苄酯 (BBP)	○	○
鄰苯二甲酸二異辛酯 (DEHP)	○	○
鄰苯二甲酸二異壬酯 (DINP)	○	○

注：○：表示該有害物質在該部件的均質材料中的含量均在現行有關產品有害物質限制標準的限量要求範圍內。
×：表示該有害物質至少在該部件的某一均質材料中的含量超出現行有關產品有害物質限制標準的限量要求。
（以上表格內容為依據：單位提供有關部門出具的有關產品有害物質限制使用清單的有關資料。）

備注：
1. 有害物質含量超出現行有關產品有害物質限制標準的限量要求，但是現行有關產品有害物質限制標準尚未規定限量的，或現行有關產品有害物質限制標準尚未規定限量的，或現行有關產品有害物質限制標準尚未規定限量的，或現行有關產品有害物質限制標準尚未規定限量的。
2. 部件名稱欄填寫的不同，產品可能不包括以上所有部件，請以產品實際情況為準。

刷頭更換安裝方法

C-1 安裝：保持刷毛朝向牙齿并按压刷毛，将刷头对准机身上的连接槽头，正向装下即可。
C-2 拆卸：将刷头朝反方向用力即可拆出。

Brush Head Installation and Removal

B-1 Installation: Align the brush head with the metal shaft on the handle, ensuring the bristles face the same direction as the button. Press the brush head down firmly until it is fully secured.
B-2 Removal: Pull the brush head upwards with force to detach it from the handle.

Operating Instructions

1. Install the brush head firmly onto the handle. Apply a suitable amount of toothpaste onto the bristles.
2. Place the bristles gently against the junction of your teeth and gums, holding the brush at a 45°angle to the tooth surface. (C-1)
3. Press the power button to start. Slowly move the brush head horizontally across each tooth.
4. Divide your mouth into four sections: Lower left, upper right, lower left, lower right. Spend 10 seconds brushing the outer, inner, and chewing surfaces of each section. (C-2)
5. The toothbrush will automatically pause for 30 seconds to remind you to move to the next quadrant. The appliance will automatically turn off after 2 minutes of continuous use.
6. Within 3 seconds of turning on the device, pressing the button will switch the mode. The switching sequence is: Whitening → Clean → Sensitive → Polish → Massage → Off → Clean.
7. If no button is pressed within 3 seconds, pressing the button again will turn off the device.
8. The mode used in the current session will be memorized and set as the default mode for the next time you turn on the device.
9. Rinse the brush thoroughly with clean water after use. Once a month, soak the handle (with the charging cover tightly closed) in water below 40℃ (104℉) for a deep clean.

Charging Instructions

1. When the red indicator light flashes or the device fails to turn on, the battery is low and needs to be charged.
2. Connect the toothbrush to a USB charger or a device with a USB port using the original charging cable provided.
3. The indicator light will give red duty during charging. Once fully charged, the light will turn green and then turn off automatically to prevent overcharging.
4. If the indicator light does not illuminate during the first 5 minutes of charging (especially during the first use or after long periods of inactivity), this is a normal self-protection mechanism due to extremely low battery levels. The light will turn on automatically shortly after.

Features

1. Up to 42,000 micro-vibrations per minute for a deep and thorough clean
2. Five cleaning modes (Whitening, Clean, Sensitive, Polish, and Massage) to meet personalized gum sensitivity needs
3. Ergonomic design that fits perfectly in your hand, ensuring anti-moisture-resistant for a comfortable grip
4. Built-in high-capacity eco-friendly lithium battery. A single full charge lasts up to 45 days (based on 2 minutes of use, twice a day, for a standard battery)
5. IPX7 waterproof rating allows for safe use in the shower and easy cleaning under running water
6. Smart timer with a 30-second quadrant alert and a 2-minute auto-shutoff, plus a convenient memory function.

取扱説明書 (JP)

ご使用の前に

1. ご使用の前にかならずこの取扱説明書をよくお読みの上、正しくお使いください。この説明書は大切に保管してください。
2. 身体の不自由な方、知覚・精神機能に障がいのある方、および十分な知識と経験のない方（お子様を含む）は、ご自身の責任において安全にご使用いただけるよう、管理者による指導を行うか、あるいはご使用を禁じてください。
3. お子様が本製品で遊ばないように、十分に注意して保管してください。
4. 本製品はクラスIIの機器です。本体に記載されている安全特別低電圧（SELV）電源でのみ動作します。電源アダプターの出力端子における実測最大出力は15W未満であることを確認してください。充電ケーブルを使用して充電する場合、電源アダプターは、定格出力電圧5V、定格出力電流1A、かつ関連する国家規格 GB/T 4706.1-2024に適合する安全特別低電圧（SELV）の要件を満たしていなければなりません。
5. 充電ポートは完全に乾燥してから充電を実施してください。パッケージに同梱されている純正品の充電ケーブルのみをご使用ください。
6. 本製品には交換不可能なバッテリーが内蔵されています。
7. 異常な音、発熱、変色の現象、または故障が発生した場合は、直ちに使用を中止し、スイッチを切り、電源プラグを抜いてください。
8. 製品の分解、修理、改造は絶対にしないでください。不具合が発生した場合は、当社までご連絡ください。当社は専門技術者による修理、または修理が必要な場合は、必ず弊社専門技術者が対応いたします。工具を使用する際は、基本的な安全規則に従い、怪我をしないように保護措置を講じてください。
9. 本製品は、お子様、一般顧客の高い物の近くに、これに類する環境下では使用しないでください。
10. 過去2ヶ月以内に口腔内や歯茎の手術を受けたことがある場合は、ご使用の前に歯科医にご相談ください。
12. 本製品は、歯茎、舌の清掃専用です。他の目的で使用しないでください。
13. 毛先が潰れたブラシの使用は避けてください。磨耗した状態が見られ次第すぐに交換してください。ブラシは3ヶ月に1回の交換を推奨します。
14. 製品は、当社純正の専用ブラシのみをご使用ください。
15. 使用する歯磨粉に重曹成分（炭酸水素ナトリウム）、過酸化水素、炭酸成分等が含まれる場合は、プラスチック部品の劣化防止のため、毎回ご使用後によく洗い流してください。

製品仕様

型番：SG-2750 (S5)
使用電源容量：5 ⎓
定格入力：1.5W
材質：ABS / TPE / ナイロン
充電時間：≤4時以内
製品寸法：27×26×247mm（ブラシを含む）
原産地：中国
防水等級：IPX7

各部の名称

A-1 ブラシ（替えブラシ）
A-2 電源・モード切替ボタン
A-3 ハンドル（本体）
A-4 充電表示ランプ
A-5 充電ポート
A-6 トラベルケース
A-7 モード
ホワイトニング
クリーン
ソフト
ポリッシュ
マッサージ

故障診断

状況	可能原因	解決措置
振動強度減弱	1.歯ブラシの長期使用による毛先の摩耗	新品ブラシに交換
歯ブラシ作動時間短	1.歯ブラシが充電されていない 2.バッテリー残量不足	1.充電を推奨します 2.バッテリー交換
歯ブラシ不作動	1.バッテリー残量不足 2.内部故障	1.充電を推奨します 2.修理・交換

電池交換処理

本製品使用的是锂电池，產品壽命終止時，請勿自行拆卸，請聯繫客服中心，我們會為您提供專業的電池拆卸服務。若有疑問請直接與我們的售後部門。
拆除電池需要準備以下工具：螺子、剪刀。

刷頭交換安裝方法

B-1 安裝：保持刷毛朝向牙齿并按压刷毛，将刷头对准机身上的连接槽头，正向装下即可。
B-2 拆卸：将刷头朝反方向用力即可拆出。

ブラシの取り付け・取り外し

B-1 取り付け：ブラシの毛先と本体のボタンが同じ方向を向いていることを確認してください。ブラシを本体に合わせ、カチッと音がするまで押してしっかりと固定してください。
B-2 取り外し：ブラシを上方向へ強く引っ張ると外れます。

ご使用方法

1. ブラシを本体にしっかりと取り付け、ブラシの毛先に適量の歯磨き粉をつけます。
2. ブラシの毛先を歯と歯茎の境目に沿って、歯の表面に対して45度の角度で当てます。(C-1)
3. 電源ボタンを押して電源を入れ、ブラシを少しゆっくと横方向に動かしながらゆっくりと歯を磨きます。
4. 口の中を左上、左下、右上、右下の4つのエリアに分けて、それぞれエリアごとに外側、内側、咬合面を10秒間磨きます。(C-2)
5. 1エリアのブラシ3分が完了 30 秒に達すると、次のエリアへ移ると 5 一時停止して お知らせします。2 分後に自動的に電源が切れます。
6. 電源投入後、3 秒以内にボタンを押すとモードを切り替えることができます。切り替え順序は：「ホワイトニング→クリーン→ソフト→ポリッシュ→マッサージ→オフ→クリーン」です。
7. 3 秒以内にボタンを操作がなかった場合、再度ボタンを押すと電源が切れます。
8. 現在使用されているモードは、次に電源を入れたときのデフォルトモードとして記憶されます。
9. 使用後は清水でよく洗い流してください。また、月に1回は40℃以下のぬるま湯に本体を浸け、深く洗浄してください。（その際は、充電ポートのふたをしっかり閉じてください。）

充電方法

1. 赤色のランプが点滅したり、電源が入らなくなったりした場合は、バッテリー残量が不足しています。充電してください。
2. 付属の専用ケーブルで本体を USB 電源（または USB ポート搭載機器）を接続してください。
3. 充電中は赤色のランプが点灯します。満充電になると緑色のランプが点灯し、過剰な充電を防ぐために自動的に消灯します。
4. 長期間使用しなかった場合や、初回使用時などに充電を開始した直後の5分間はランプが点灯しないことがあります。これはバッテリーが極端に少ないときの正常な保護機能です。その少し経過後に自動的に点灯します。ご心配なく使用ください。

製品の特長

1. 1分間に最大42000回の超小振動で、隅々まで丁寧に磨きます。
2. ホワイトニング、クリーン、ソフト、ポリッシュ、マッサージの5つのモードを搭載。歯茎の敏感さに合わせて使い分けられます。
3. 人間工学に基づいた設計で、手にしっくり馴染み、滑りにくく、高たまで安定感のある握り心地です。
4. 大容量の環境に優しいリチウム電池を内蔵。フル充電モードで 1 日 2 回（各 2 分）使用した場合、通常電池で最大 45 日間使用可能です。
5. IPX7 防水仕様。全身が水洗、使用安心。
6. 平均寿命 30 秒構成搭載。2 分間動作記録機能付。

故障診断

症状	考えられる原因	対処方法
振動の強さが弱くなった	長年使用し、ブラシの毛先がすり減った。	「ブラシの毛先を軽く押しながら使用してください。」と、「使用期間を確認してください。」
使用時間が短くなった	1.充電が完全に満たされていない 2.バッテリーの劣化	1.充分に充電してください。 2.交換時期を確認してください。
電源が入らない	1.バッテリーが完全に切れている 2.その他の不具合	1.充電してください。 2.購入店またはカスタマーサービスへご連絡ください。

電池の交換処理

本製品は内蔵リチウム電池を使用しています。製品の寿命が尽きたら、お客様の安全と環境保護のため、専門の業者に処理を依頼してください。詳細は お住まいの地域の廃棄物管理ルールに従ってください。

製品仕様

型番：SG-2750 (S5)
定格入力：5V ⎓
定格入力電力：1.5W
充電時間：≤4時以内
動作環境：5-40℃ (41-104℉)
製品寸法：27×26×247mm（ブラシを含む）
防水等級：IPX7
材質：ABS / TPE / 尼龍
原産地：中国

各部の名称

A-1 ブラシ（交換用）
A-2 電源・モード切替ボタン
A-3 ハンドル（本体）
A-4 充電表示ランプ
A-5 充電ポート
A-6 トラベルケース
A-7 モード
ホワイトニング
クリーン
ソフト
ポリッシュ
マッサージ